

## Dacia Spring Frunk Assembly instructions

1. Open the bonnet, and fix it with the metal rod on the left.
2. Remove the two screws if your car is capable to DC charging, and replace them with the two rubber covered one, that we provided. Note the position from the picture.

If your car does not have this feature, just place the rubber coated screws in.



3. Place the frunk into the front of the car, the deep part is on the left side.
4. Use the longer screws and the plates to fix the lowest part of the frunk to the existing threads underneath the module.



5. Use the shorter screws and the plates to fix the frunk to the rubber legs we provided, and were applied in step 2. As the rubber legs have some flexibility, it will allow to move with the motor
6. Fix the left side metal bracket near the battery.
7. place the mats provided to avoid rattle and items from moving around.

Thank you very much for purchasing our frunk.

If you have any questions, or issues, please feel free to contact us on +353858217224 or

evaccessoriesireland@gmail.com